



Description

OEM FO21 Tibbe profile unassembled bonnet lock to suit Ford Transit from 2006 to 2014. If you aren't sure of the part you require please either call or e-mail us with the VIN and we will help you order the right part.



6 Pin
Mechanism



Genuine Product



Tibbe Key

Features

- Supplied unassembled
- OEM Transit bonnet lock
- FO21 Tibbe profile
- 6 pin mechanism

Product Table



L33716

Unassembled