



Description

The proximity key is an optional accessory for contact-free arming and disarming of alarm panels, replacing code entry.

Features

- Several chip keys can be used with an alarm system (depending on the alarm panel)
- Functions on a completely contact-free basis
- Simply hold in front of the alarm panel or control panel
- Easy to operate without entering a code – never “forget your PIN code” again
- For arming/disarming the Secvest 2WAY and Terxon alarm systems

Product Table



L22473
Black