



COOPERBOLT Alarmed Door Bolt 103 Series



Description

The Cooperbolt emergency door bolts are an effective way to lock doors and still allow immediate exit in an emergency by pressing the push pad. The 103 series is alarmed and designed for use on outward opening doors. The alarm is battery powered and sounds when the door is opened. The key is then used to re-lock the door and silence the alarm.

Features

- Supplied with screws, flat keep, batteries and door sign
- Reset key resets bolt & silences alarm
- Box keeps available to special order
- Model 103S includes key operated on/off switch to de-activate the alarm allowing access without alarm sounding
- Push pad operation releases bolt, activates alarm & opens door
- Alarmed emergency bolt for outward opening doors

Product Table



L8462
Key Switch



6650
No Key Switch