



Description

The Cooperbolt emergency door bolts are an effective way to lock doors and still allow immediate exit in an emergency by pressing the push pad. The 101 series is designed for use on outward opening single doors, and the key is used to re-lock the door after use.

Features

- Supplied with screws, flat keep and door sign
- Box keeps available to special order
- Once opened, bolt can only be reset by key holder
- Door is bolted except in an emergency

Product Table



8589

Reversible