

MINDER TV Simulator







Description

The MINDER TV Simulator is lightweight and portable, with a simple easy access on/off switch for rapid deployment. It simulates TV acting as an effective deterrent to potential intruders and requires 3 x AA batteries (not included).

Features

- Requires 3 x AA batteries (not included)
- Lightweight and portable
- Easy access on/off switch
- Simulates TV to deter potential intruders

Product Table



L31378 SIMTV18