



GEZE OL Line Manual Spring Stop



Description

The GEZE OL Line Manual Spring Stop is a helical spring stop suitable for use with the Geze Inner Cable and can be threaded on to the end of the cable to adjust the opening stroke.

Features

- Adjusts the opening stroke when threaded onto the end of the cable
- For use with the Geze Inner Cable
- Helical spring stop

Product Table



L31411

Silver